

GEMINI CNTRL-7



VIRTUAL DJ CONFIGURATION

Make sure you have all the necessary items for operation:

- CNTRL-7
- Virtual DJ installed on your computer
- USB cable
- RCA or XLR output cords
- Monitors
- Headphones

CONNECTING/CONFIGURING

1. Plug the USB cable into the rear port of the CNTRL-7 and the other end into a USB input on your computer.
2. Open Virtual DJ
3. In the upper right hand corner of the Virtual DJ screen, click on CONFIG.
4. Set the CONFIG to the following and click APPLY and OK when finished.
 - Inputs -> NONE
 - Outputs -> HEADPHONES
(Master: Left Channel /
Headphones: Right Channel)
 - Sound Card -> 2 CARDS
(1st Selection - USB AUDIO MAIN)
(2nd Selection - USB AUDIO PHONE)
5. Use the BROWSE dial in the center of the CNTRL-7 to find tracks within your computer in Virtual DJ's file browser. Then use the LOAD A and LOAD B buttons to load tracks onto the decks for playback.
6. Use the MASTER, BOOTH, and HEADPHONE VOLUME knobs to control the level of playback for the master and cue mixes.
7. All other functions on the CNTRL-7 directly correspond to an onscreen function of VIRTUAL DJ and you will see them change as you move them.



Have fun DJing with the CNTRL-7!

VIRTUAL DJ
LIMITED EDITION

QUICKSTART GUIDE

WWW.GEMINISOUND.COM

gemini[®]
DJ